




# AC power connection to RXC-3000



240 VAC single phase wiring



208/240 VAC three phase wiring



**Never Exceed 250VAC into the power supply**

**Warnings:**  
 Turn off ALL power before working on any electrical equipment.  
 Follow all applicable electrical and safety rules and regulations.  
 This is only an example. Your contactor and wiring may differ.  
 Electrical work should only be performed by licensed and qualified personnel.