



Instructions for Genave ComStarG4 programming software.

Thumbdrive Installation to Computer Disk drive.

- 1) Insert the thumbdrive into your computer. The computer should automatically find the drive and install it as a removable disk drive.
- 2) If the program does not automatically install, you may need to use Windows Explorer to select the drive and manually start the installation program: **setup.exe**

The program will create and install to the directory **C:\Program Files\Genave**

The program will also install all of the files you need into the Genave directory.

The program will also ask if you want a desktop icon.

The first time you install ComStarG4 on your computer, select the option to install the USB Drivers.

- 3) Attach your USB cable to the RXC unit and run the **ComStarG4** program.
- 4) The first time your run the program, click **Edit->Preferences** and select the USB drive.

The file that holds all of the configuration data for your Genave product will automatically load when you start ComstarG4. If you make changes to the file, use "SAVE AS" and save the new file to the hard drive. It is best if you also save the file to the thumbdrive. This will be your backup copy of the changes.

KEEP YOUR THUMBDRIVE SAFE. If you need to return your Genave product for service, you will need to send us the thumbdrive along with the unit if you have made changes to the data files in the field. This will be our only way of knowing what the unit has been programmed to do.

Note: Data files all end with a .cg4 suffix (such as Siren-3000.cg4).